


Position of Parts in Seat <LHD Front Seat Before Sep. 2012 Production>






























- R 4 Front Side Airbag Squib Circuit RH
- R 49 Front Seat Inner Belt Assembly RH
- R 65 Junction Connector

- S 1 Front Side Airbag Squib Circuit LH
- S 17 Front Seat Inner Belt Assembly LH

- e 41 Front Power Seat Cushion Position Sensor LH
- e 42 Front Seat Heater LH
- e 43 Front Power Seat Lift Position Sensor LH
- e 44 Front Power Seat Lift Position Motor Assembly LH
- e 45 Front Power Seat Control ECU and Switch LH
- e 46 Front Power Seat Control ECU and Switch LH
- e 47 Front Power Seat Reclining Position Motor Assembly LH
- e 48 Front Power Seat Reclining Position Sensor LH
- e 49 Front Lumbar Support Up and Down Motor Assembly LH
- e 51 Front Seat Climate Controller Seat Back LH
- e 52 Front Lumbar Support Forward and Back Motor Assembly LH
- e 53 Front Seat Headrest Adjuster LH
- e 54 Front Seat Inner Belt Assembly LH
- e 55 Junction Connector
- e 56 Front Headrest Position Sensor RH
- e 60 Active Headrest Control ECU RH
- e 63 Junction Connector
- e 64 Junction Connector
- e 73 Active Headrest Control ECU LH
- e 86 Junction Connector
- e 87 Junction Connector
- e 91 Front Power Seat Vertical Position Sensor RH
- e 95 Front Power Seat Slide Position Motor Assembly RH
- e 96 Front Power Seat Vertical Position Motor Assembly RH
- e 97 Front Power Seat Reclining Position Motor Assembly RH
- e 98 Active Headrest Airbag Squib Circuit RH
- e 100 Front Power Seat Slide Position Motor Assembly LH
- e 101 Front Power Seat Vertical Position Motor Assembly LH
- e 102 Front Power Seat Cushion Control Motor Assembly LH
- e 103 Front Power Seat Reclining Position Motor Assembly LH
- e 104 Active Headrest Airbag Squib Circuit LH

- z 61 No.1 Interior Illumination Light Assembly RH
- z 62 No.1 Interior Illumination Light Assembly LH

Position of Parts in Seat <LHD Front Seat Before Sep. 2012 Production>



Position of Parts in Seat <LHD Front Seat Before Sep. 2012 Production>

