
























Position of Parts in Instrument Panel <LHD From Sep. 2012 Production>



L 160	Driver Monitor Camera
L 168	Tire Pressure Monitor Initiator Driver
L 170	No. 1 Stereo Jack Adapter Assembly
L 171	Room Light Control Relay
L 172	No. 1 Interior Illumination Light Assembly
L 173	Telephone Antenna Assembly
L 174	Multi-Media Module Receiver Assembly
L 175	Tire Pressure Warning ECU and Receiver
L 176	Accessory Meter Assembly
L 177	Multi-Media Module Receiver Assembly
L 178	Accessory Meter Assembly
L 179	Junction Connector
L 180	Junction Connector
L 181	Junction Connector
L 182	Junction Connector
L 183	Junction Connector
L 184	Junction Connector
L 185	Junction Connector
L 186	Junction Connector
L 187	Junction Connector
L 188	Junction Connector
L 189	Multi-Media Module Receiver Assembly
L 190	Multi-Media Module Receiver Assembly
L 191	Telematics Transceiver
L 192	No. 1 Stereo Jack Adapter Assembly
L 193	Multi-Media Module Receiver Assembly
L 194	Multi-Media Module Receiver Assembly
L 195	Telematics Transceiver
L 196	Telephone Antenna Assembly
L 197	Telematics Transceiver
L 198	No. 1 Stereo Jack Adapter Assembly
L 199	Multi-Media Module Receiver Assembly
L 200	Junction Connector
L 201	Vehicle Approaching Speaker Controller
L 202	Vehicle Approaching Speaker Switch
L 203	Telephone Antenna Assembly
L 204	Telematics Transceiver

Position of Parts in Instrument Panel <LHD From Sep. 2012 Production>



Position of Parts in Instrument Panel <LHD From Sep. 2012 Production>

