






L 118	Junction Connector
L 119	Junction Connector
L 120	Junction Connector
L 121	Junction Connector
L 124	Combination Meter
L 125	Turn Signal Flasher Assembly
L 126	Spiral Cable Sub-Assembly
L 127	Telematics Transceiver
L 128	Hazard Warning Signal Switch Assembly
L 129	Headlight Swivel Main Switch
L 130	Radio Receiver Assembly
L 131	Multi-Media Module Navigation Assembly
L 132	Display & Navigation Module Display
L 133	Display & Navigation Module Display
L 134	Display & Navigation Module Display
L 135	Display & Navigation Module Display
L 136	Display & Navigation Module Display
L 137	Display & Navigation Module Display
L 138	Display & Navigation Module Display
L 142	Display & Navigation Module Display
L 143	Parking Assist ECU
L 144	Display & Navigation Module Display
L 145	IEEE Connector
L 146	Multi-Media Module Navigation Assembly
L 148	Telephone Antenna Assembly
L 149	Telematics Transceiver
L 150	Display & Navigation Module Display
L 151	No. 1 Stereo Jack Adapter Assembly
L 153	Telematics Transceiver
L 154	Display & Navigation Module Display
L 155	Diode (Turn Signal)
L 156	Junction Connector
L 157	Option Connector (Bus Buffer)


L118
Gray




L119
Gray




L120
Black




L121
White




L124
Black




L125
Black




L126
Black




L127
White




L128
White




L129
Black




L130
White




L131
White




L132
White




L133
White




L134
White




L135
White




L136
Blue



L137
White



L138
White



L142
Blue



L143
White



