




R 1 Suspension Control ECU
R 5 Airbag ECU Assembly
R 48 Junction Connector

S 8 Airbag ECU Assembly
S 9 Rear Cigarette Lighter Assembly
S 79 Junction Connector
S 81 Junction Connector

u 1 Radio Receiver Assembly

z 1 A/C Amplifier , A/C Blower Assembly
z 2 Cruise Control Main Switch Assembly , Spiral Cable Sub-Assembly
z 5 Combination Switch Assembly , Integration Control and Panel Assembly
z 6 Headlight Dimmer Switch Assembly , Windshield Wiper Switch Assembly
z 7 Spiral Cable Sub-Assembly , Steering Pad Switch Assembly with Modulator
z 8 Steering Pad Switch Assembly with Modulator , Steering Pad Switch Assembly
z 11 Driver Side Squib Circuit , Spiral Cable Sub-Assembly
z 12 Driver Side Squib 2nd Step Circuit , Spiral Cable Sub-Assembly
z 13 Spiral Cable Sub-Assembly , Steering Wheel Heater Control Assembly
z 17 Front Passenger Side Squib 2nd Step Circuit
z 18 Front Passenger Side Squib Circuit
z 19 Hazard Warning Signal Switch Assembly
z 20 Front Blower with Fan Motor Sub-Assembly
z 52 Console Box Light Sub-Assembly

