


Position of Parts in Instrument Panel <RHD From Sep. 2012 Production>

- * 2:5-Seater w/ Ottoman
- * 3:5-Seater w/o Ottoman
- * 5:Before Oct. 2014 Production
- * 6:From Oct. 2014 Production
- * 7:w/ Console Display
- * 8:w/ Roof Display




A 33 Driving Support ECU Assembly
A 36 Accelerator Pedal Sensor Assembly
A 37 Headlight Swivel ECU Assembly
A 38 Short Connector (Height Control)
A 39 Suspension Control ECU
A 41 Steering Control ECU
A 42 Steering Control ECU
A 43 Steering Control ECU
A 65 Junction Connector
A 66 Junction Connector
A 67 Junction Connector
A 68 Main Body ECU
A 89 Junction Connector
A 94 Brake Pedal Stroke Sensor Assembly
A 95 Stop Light Switch Assembly


M 1 Front No.3 Speaker Assembly
M 2 Automatic Light Control Sensor
M 3 Ion Generator Sub-Assembly

R 1 Suspension Control ECU
R 5 Airbag ECU Assembly
R 48 Junction Connector
R 79 Console Box Illumination Light Front
R 85 Console Box Illumination Light Rear
R 98 Disc Player Assembly
R 105 Television Display Assembly
R 107 Disc Player Assembly
R 111 Television Display Assembly
R 112 Television Display Assembly
R 116 Television Display Assembly
R 120 Television Display Assembly


A 36
Black




A 38
Blue




A 42
White



A 66
Black



A 89
White



M 3
White

