




- L 81 No.1 Interior Illumination Light Assembly LH
- L 82 Short Connector (Height Control)
- L 83 Luggage Compartment Door Opening Cancel Switch Assembly
- L 84 Front No.2 Speaker Assembly RH
- L 85 Airbag Cutoff Switch
- L 86 Front Passenger Side Knee Airbag (Lower No.1 Instrument Panel Airbag Assembly)
- L 87 Front Duct Sensor RH
- L 88 Suspension Control ECU
- L 90 Parking Assist ECU
- L 91 Parking Assist ECU
- L 92 Front Register Illumination Center
- L 94 Junction Connector
- L 95 Junction Connector
- L 97 Junction Connector
- L 98 Junction Connector
- L 99 Junction Connector
- L 100 Junction Connector
- L 101 Tire Pressure Warning ECU and Receiver
- L 102 Network Gateway ECU
- L 103 Tire Pressure Warning ECU and Receiver
- L 108 Short Connector (Cigarette Lighter)
- L 109 Short Connector (Cigarette Lighter)
- L 110 Junction Connector

Position of Parts in Instrument Panel <RHD From Nov. 2009 Production until Sep. 2012 Production>

