


























Position of Parts in Seat <RHD Rear Seat 5-Seater w/ Power Seat Before Sep. 2012 Production>



- f 2 Seat Vibrator Assembly
- f 3 Rear Seat Heater RH
- f 4 Rear Power Seat Control ECU Assembly RH
- f 5 Rear Power Seat Control ECU Assembly RH
- f 6 Rear Seat No.1 Headrest Adjuster Sub-Assembly RH
- f 7 Rear Seat Climate Control ECU RH
- f 8 Rear Seat Climate Control ECU RH
- f 9 Rear Power Seat Fold Position Motor RH Assembly
- f 10 Rear Power Seat Fold Position Sensor RH
- f 11 Rear Seat Climate Fan Motor Seat Back RH
- f 12 Rear Seat Climate Controller Seat Back RH
- f 16 Rear Power Seat Motor Assembly RH
- f 19 Rear Side Airbag Assembly RH
- f 20 Junction Connector
- f 22 Seat Vibrator Assembly
- f 23 Rear Seat Heater LH
- f 24 Rear Power Seat Control ECU Assembly LH
- f 25 Rear Power Seat Control ECU Assembly LH
- f 26 Rear Seat No.1 Headrest Adjuster Sub-Assembly LH
- f 27 Rear Seat Climate Control ECU LH
- f 28 Rear Seat Climate Control ECU LH
- f 29 Rear Power Seat Fold Position Motor Assembly LH
- f 30 Rear Power Seat Fold Position Sensor LH
- f 31 Rear Seat Climate Control Blower LH
- f 32 Rear Seat Climate Controller Seat Back LH
- f 33 Rear Power Seat Motor Assembly LH
- f 35 Rear Side Airbag Assembly LH
- f 36 Junction Connector
- f 37 Rear Seat Airbag Assembly LH
- f 38 Rear Seat Inner Belt Assembly RH
- f 39 Rear Power Seat Control ECU Assembly RH
- f 40 Rear Power Seat Fold Position Motor Assembly RH
- f 41 Rear Power Seat Position Motor RH (Lumbar Support Position)
- f 42 Rear Seat Inner Belt Assembly LH
- f 43 Rear Power Seat Control ECU Assembly LH
- f 44 Rear Power Seat Position Motor LH (Lumbar Support Position)
- f 45 Rear Power Seat Fold Position Motor Assembly LH

Position of Parts in Seat <RHD Rear Seat 5-Seater w/ Power Seat Before Sep. 2012 Production>



Position of Parts in Seat <RHD Rear Seat 5-Seater w/ Power Seat Before Sep. 2012 Production>

