






L164(A), L165(B), L166(C), L174(D), L189(E), L194(F), L193(G), L199(H)
Multi-Media Module Receiver Assembly



S101
Television Camera
Assembly

L192(A), L198(B)
No. 1 Stereo Jack Adapter Assembly


L164(A), L165(B), L166(C), L174(D), L189(E), L194(F), L193(G), L199(H)
Multi-Media Module Receiver Assembly



L192(A), L198(B)
No. 1 Stereo Jack Adapter Assembly


: There is no wire color information.

L164(A), L165(B), L166(C), L174(D), L189(E), L194(F), L193(G), L199(H)
Multi-Media Module Receiver Assembly




z101(E)
Steering Pad Switch Assembly


L164(A), L165(B), L166(C), L174(D), L189(E), L194(F), L193(G), L199(H)
Multi-Media Module Receiver Assembly




L164(A), L165(B), L166(C), L174(D), L189(E), L194(F), L193(G), L199(H)
Multi-Media Module Receiver Assembly




L164(A), L165(B), L166(C), L174(D), L189(E), L194(F), L193(G), L199(H)
Multi-Media Module Receiver Assembly



L164(A), L165(B), L166(C), L174(D), L189(E), L194(F), L193(G), L199(H)
Multi-Media Module Receiver Assembly




L164(A), L165(B), L166(C), L174(D), L189(E), L194(F), L193(G), L199(H)
Multi-Media Module Receiver Assembly




Note :
Please refer to the Multiplex Communication System (CAN) section
for information regarding the shielded communication lines.


L164(A), L165(B), L166(C), L174(D), L189(E), L194(F), L193(G), L199(H)
Multi-Media Module Receiver Assembly




L164(A), L165(B), L166(C), L174(D), L189(E), L194(F), L193(G), L199(H)
Multi-Media Module Receiver Assembly




L164(A), L165(B), L166(C), L174(D), L189(E), L194(F), L193(G), L199(H)
Multi-Media Module Receiver Assembly




L164(A), L165(B), L166(C), L174(D), L189(E), L194(F), L193(G), L199(H)
Multi-Media Module Receiver Assembly




L164(A), L165(B), L166(C), L174(D), L189(E), L194(F), L193(G), L199(H)
Multi-Media Module Receiver Assembly



L164(A), L165(B), L166(C), L174(D), L189(E), L194(F), L193(G), L199(H)
Multi-Media Module Receiver Assembly







* 3 : w/ Telematics System
* 4 : w/o Telematics System




L164(A), L165(B), L166(C), L174(D), L189(E), L194(F), L193(G), L199(H)
Multi-Media Module Receiver Assembly




R104(B), R105(C), R112(A), R115(E), R116(D), R120(F), z99(H), z100(G)
Television Display Assembly





R104(B), R105(C), R112(A), R115(E), R116(D), R120(F), z99(H), z100(G)
Television Display Assembly




R104(B), R105(C), R112(A), R115(E), R116(D), R120(F), z99(H), z100(G)
Television Display Assembly




R104(B), R105(C), R112(A), R115(E), R116(D), R120(F), z99(H), z100(G)
Television Display Assembly




R104(B), R105(C), R112(A), R115(E), R116(D), R120(F), z99(H), z100(G)
Television Display Assembly




R104(B), R105(C), R112(A), R115(E), R116(D), R120(F), z99(H), z100(G)
Television Display Assembly



R104(B), R105(C), R112(A), R115(E), R116(D), R120(F), z99(H), z100(G)
Television Display Assembly




R104(B), R105(C), R112(A), R115(E), R116(D), R120(F), z99(H), z100(G)
Television Display Assembly




R98(A), R107(B), z95(C), z96(D)
Disc Player Assembly

R104(B), R105(C), R112(A), R115(E), R116(D), R120(F), z99(H), z100(G)
Television Display Assembly



R98(A), R107(B), z95(C), z96(D)
Disc Player Assembly

R104(B), R105(C), R112(A), R115(E), R116(D), R120(F), z99(H), z100(G)
Television Display Assembly




*11 : Roof Type
*12 : Console Type
*13 : 4-Seater
*14 : 5-Seater

: There is no wire color information.

R98(A), R107(B), z95(C), z96(D)
Disc Player Assembly


R104(B), R105(C), R112(A), R115(E), R116(D), R120(F), z99(H), z100(G)
Television Display Assembly



- *11 : Roof Type
- *12 : Console Type
- *13 : 4-Seater
- *14 : 5-Seater
- *15 : LHD Console Type
- *16 : LHD Roof Type
- *17 : RHD Console Type
- *18 : RHD Roof Type


R98(A), R107(B), z95(C), z96(D)
Disc Player Assembly

R104(B), R105(C), R112(A), R115(E), R116(D), R120(F), z99(H), z100(G)
Television Display Assembly






R98(A), R107(B), z95(C), z96(D)
Disc Player Assembly

R104(B), R105(C), R112(A), R115(E), R116(D), R120(F), z99(H), z100(G)
Television Display Assembly



R104(B), R105(C), R112(A), R115(E), R116(D), R120(F), z99(H), z100(G)
Television Display Assembly




S109(A), S110(B), Y7(E), Y8(F), o4(C), o5(D)
Video Terminal




R98(A), R107(B), z95(C), z96(D)
Disc Player Assembly

R104(B), R105(C), R112(A), R115(E), R116(D), R120(F), z99(H), z100(G)
Television Display Assembly




R98(A), R107(B), z95(C), z96(D)
Disc Player Assembly

R104(B), R105(C), R112(A), R115(E), R116(D), R120(F), z99(H), z100(G)
Television Display Assembly



R98(A), R107(B), z95(C), z96(D)
Disc Player Assembly


: There is no wire color information.




*11 : Roof Type
*12 : Console Type
*13 : 4-Seater
*14 : 5-Seater

: There is no wire color information.


R114(A), R117(B), R118(C), R119(D)
Multi-Display Controller Sub-Assembly






*11 : Roof Type
*12 : Console Type
*13 : 4-Seater
*14 : 5-Seater


: There is no wire color information.



*13 : 4-Seater
*14 : 5-Seater


: There is no wire color information.






*13 : 4-Seater
*14 : 5-Seater


: There is no wire color information.




A 13
White




A 19
Black




A 21
Gray




A 65
White




A 67
Black




A 76
Gray




A 89
White




E 49
Gray




E 58
Gray







































L 9
White























L 11
White


















































PA

White




PJ

Gray




PK

Gray




AS2

White




LA1






White




LA3

White







NR3
White




NS3
White





OQ1
White





OQ2
White





OR1
White





OS1
White









RL2
White




RL8
White







zS5
White



zS7
White

