



[Engine Room R/B No. 1 and Engine Room J/B No. 1 Inner Circuit]




[Engine Room R/B No. 1 and Engine Room J/B No. 1 Inner Circuit]

- * 4:10A ETCS (8GR-FKS)
30A ETCS (V35A-FTS)
- * 5:25A EFI-MAIN NO.1 (8GR-FKS)
30A EFI-MAIN NO.3 (V35A-FTS)
- * 6:20A EDU (8GR-FKS)
30A VVT NO.1 (V35A-FTS)




(Cont. Next Page)

[Engine Room R/B No. 1 and Engine Room J/B No. 1 Inner Circuit]



[Engine Room R/B No. 1 and Engine Room J/B No. 1 Inner Circuit]

(Cont'd)



(Cont. Next Page)

[Engine Room R/B No. 1 and Engine Room J/B No. 1 Inner Circuit]

(Cont'd)

* 8:EFI-MAIN NO.1 Relay (8GR-FKS)
VVT NO.1 Relay (V35A-FTS)

