


Position of Parts in Instrument Panel <LHD>




- L 1 No. 1 Short Connector
- L 2 No. 2 Short Connector
- L 31 Certification ECU Assembly
- L 36 Acceleration Sensor Assembly RH
- L 37 Airbag ECU Assembly
- L 47 Acceleration Sensor Assembly LH
- L 64 Airbag ECU Assembly
- L 68 No. 1 Rear Power Outlet Socket Assembly
- L 99 No. 2 Power Outlet Socket Assembly
- L 115 No. 10 CAN Junction Connector
- L 116 No. 11 CAN Junction Connector
- L 117 No. 12 CAN Junction Connector
- L 118 No. 13 CAN Junction Connector
- L 127 No. 24 CAN Junction Connector
- L 128 No. 25 CAN Junction Connector
- L 130 No. 6 CAN Junction Terminal
- L 140 Disk Player Assembly
- L 145 Mayday Battery
- L 162 Disk Player Assembly
- L 188 Option Connector (Front Scuff Plate Light RH)
- L 189 Option Connector (Front Scuff Plate Light LH)

- z 1 Steering Wheel Switch Housing , Steering Sensor
- z 2 Windshield Wiper Switch Assembly ,Steering Wheel Switch Housing
- z 3 Driver Side Squib Circuit (Horn Button Assembly) , Spiral Cable with Sensor Sub-Assembly
- z 4 Driver Side Squib Circuit (Horn Button Assembly) , Spiral Cable with Sensor Sub-Assembly
- z 5 Transmission Shift Switch Assembly , Spiral Cable with Sensor Sub-Assembly
- z 6 Steering Pad Switch Assembly , Spiral Cable with Sensor Sub-Assembly
- z 7 Steering Wheel Assembly , Spiral Cable with Sensor Sub-Assembly
- z 11 Air Conditioning Harness Assembly , Air Conditioning Amplifier Assembly
- z 22 Air Conditioning Harness Assembly , Air Conditioning Amplifier Assembly
- z 35 Turn Signal Switch , Steering Wheel Switch Housing


Position of Parts in Instrument Panel <LHD>

L1
Yellow




90980-12D87

L2
Yellow



90980-12D87

L31
White




90980-12B77

L36
Black



90980-10845

L37
Yellow




90980-12C54

L47
Black




90980-10845

L64
Yellow



90980-12C55

L68
White




90980-12498

L99
Black



90980-10601


L115
White



90980-12C68


Position of Parts in Instrument Panel <LHD>

L116
White




90980-12C68

L117
White




90980-12C68

L118
White




90980-12C68

L127
Blue




90980-12372

L128
White




90980-12C68

L130
White



82824-30470

L140
White



90980-12553

Position of Parts in Instrument Panel <LHD>

