





















Luggage Compartment Door Opener and Closer (LHD), Power Trunk Lid (LHD)

G12
Black




90980-12C62

G13
Black




90980-12C63

G17
Black




90980-12C61

G66
Black




90980-12912

G71
White



90980-12B78

G73
White




90980-12366

G74
Blue




90980-10825

G109
Black




90980-12B54

G110
White




90980-12D86

G119
Blue










90980-12B54

G120
White




90980-12A58

Luggage Compartment Door Opener and Closer (LHD), Power Trunk Lid (LHD)




Luggage Compartment Door Opener and Closer (LHD), Power Trunk Lid (LHD)

L2
Yellow




90980-12D87

L10
White




90980-12444

L12
White




90980-12812

L16
Black




90980-12366

L31
White




90980-12B77

L48
White




90980-12552

L89
Black




90980-12808

L115
White




90980-12C68

L116
White



90980-12C68

L131
White




90980-12C68

L173
Gray










90980-12043

L174
Gray




90980-50024

Luggage Compartment Door Opener and Closer (LHD), Power Trunk Lid (LHD)




Luggage Compartment Door Opener and Closer (LHD), Power Trunk Lid (LHD)

GL3
Gray




90980-12B20




90980-12B19

GL5
White




90980-12372




90980-12371

KL1
White




90980-12D82




90980-12D81

KL2
White



90980-12D82



90980-12D81

