





















Position of Parts in Body <RHD>

* 2: Integration Type
* 3: Non-Integration Type



- L 3 Rear Height Control Pressure Sensor
- L 5 Radio Setting Condenser (Noise Filter)
- L 6 Radio Setting Condenser (Noise Filter)
- L 7 Stereo Component Equalizer Assembly
- L 8 Luggage Compartment Light Assembly
- L 9 Luggage Compartment Light Assembly
- L 10 Multiplex Network Door ECU
- L 11 Auto Curtain Control Relay (Rear Window Shade Assembly)
- L 12 Luggage Door Closer Assembly
- L 13 Rear No.2 Speaker Assembly RH
- L 14 Rear No.2 Speaker Assembly LH
- L 15 Rear No. 3 Speaker Assembly
- L 16 Door Control Switch
- L 18 Clearance Warning ECU Assembly
- L 21 No. 2 Clearance Warning Buzzer
- L 22 Fuel Pump Assembly (Fuel Tank Assembly)
- L 23 Fuel Sender Gage Assembly(Fuel Tank Assembly)
- L 24 Seat Belt Pretensioner LH (Front Seat Outer Belt Assembly LH)
- L 26 Seat Belt Motor RH (Front Seat Outer Belt Assembly RH)
- L 27 Seat Belt Motor LH (Front Seat Outer Belt Assembly LH)
- L 30 Absorber Control ECU
- L 32 Front Door Courtesy Light Switch Assembly RH
- L 33 Rear Airbag Sensor Assembly RH
- L 34 Seat Belt Pretensioner RH (Front Seat Outer Belt Assembly RH)
- L 35 Tension Reducer RH (Front Seat Outer Belt Assembly RH)
- L 38 No. 2 Fuel Sender Gage Assembly
- L 39 No.2 Side Airbag Sensor Assembly RH
- L 40 Rear Door Courtesy Light Switch Assembly RH
- L 41 Curtain Shield Airbag Assembly RH
- L 42 Rear Window Defogger (Back Window Glass)
- L 43 Seat Belt PretensionerRH (Rear Seat Outer Belt Assembly RH)
- L 45 Rear Skid Control Sensor Wire RH
- L 46 Absorber Control ECU
- L 48 Electrical Key & Tire Pressure Monitoring System Receiver Assembly
- L 49 Smart Door Control Receiver Assembly

Position of Parts in Body <RHD>



Position of Parts in Body <RHD>

