
















Position of Parts in Engine Compartment <LHD>

- * 3: Prior September 2018 2WD
- * 4: September 2018 or later 2WD
- * 5: Prior September 2018 AWD
- * 6: September 2018 or later AWD



- A 60 Headlight Cleaner Motor and Pump Assembly
- A 61 No. 1 Semiconductor Power Integration ECU
- A 62 No. 1 Junction Connector
- A 63 No. 2 Junction Connector
- A 65 No. 1 Ground Junction Connector
- A 66 No. 1 Semiconductor Power Integration ECU
- A 68 Front Height Control Sensor Sub-Assembly LH
- A 69 Front Height Control Sensor Sub-Assembly RH
- A 70 Front Shock Absorber Assembly LH
- A 71 Front Shock Absorber Assembly RH
- A 72 Front Speed Sensor LH
- A 73 Front Speed Sensor RH
- A 74 Front Height Control Sensor Sub-Assembly LH
- A 75 Front Height Control Sensor Sub-Assembly RH
- A 79 Inverter with Converter Assembly
- A 80 Oil Pump Motor Controller
- A 81 Vehicle Approaching Speaker Assembly
- A 82 Inverter with Converter Assembly
- A 83 Swing Grille Actuator Assembly
- A 84 Inverter Water Pump Assembly (with Motor)
- A 85 Compressor with Motor Assembly
- A 86 Compressor with Motor Assembly
- A 87 Fusible Link Block Assembly
- A 88 Fusible Link Block Assembly
- A 89 Fusible Link Block Assembly
- A 90 Fusible Link Block Assembly
- A 91 Fusible Link Block Assembly
- A 92 Option Connector (HV Battery Heater)
- A 94 Inverter with Converter Assembly
- A 97 Compressor with Motor Assembly
- A 98 Compressor with Motor Assembly

Position of Parts in Engine Compartment <LHD>



Position of Parts in Engine Compartment <LHD>

