
















Position of Parts in Engine Compartment <RHD>



- A 6 Hood Courtesy Switch (Hood Lock Control Assembly)
- A 7 Wireless Door Lock Buzzer
- A 8 Brake Actuator Assembly
- A 14 Front Shock Absorber Assembly LH
- A 15 Front Airbag Sensor LH
- A 16 Front Speed Sensor LH
- A 17 Windshield Washer Motor and Pump Assembly
- A 19 Brake Fluid Level Warning Switch (Brake Master Cylinder Sub-Assembly)
- A 23 Front Shock Absorber Assembly RH
- A 24 Security Horn Assembly
- A 25 Front Skid Control Sensor Wire RH
- A 26 Front Airbag Sensor RH
- A 27 Heater Water Pump(Heater Accessory Assembly)
- A 28 Pedestrian Detection Chamber Assembly LH
- A 29 Pedestrian Detection Chamber Assembly RH
- A 31 Headlight ECU Sub-Assembly LH
- A 32 Headlight ECU Sub-Assembly RH
- A 36 Front Side Radar Sensor LH
- A 37 Front Side Radar Sensor RH
- A 38 No.1 Height Control Valve Sub-Assembly
- A 39 Air Conditioning Pressure Sensor
- A 40 Outside Air Temperature Sensor (Thermistor Assembly)
- A 41 High Pitched Horn Assembly
- A 42 Front Height Control Pressure Sensor
- A 43 Windshield Wiper Motor Assembly
- A 44 Low Pitched Horn Assembly
- A 45 Smog Ventilation Sensor
- A 46 Brake Booster Pump with Accumulator Assembly
- A 47 Brake Booster Pump with Accumulator Assembly
- A 48 Fan with Motor Assembly
- A 49 Fan with Motor Assembly
- A 51 Front Wiper Deicer (Windshield Glass)
- A 52 Pop Up Hood Lifter Assembly LH
- A 53 Pop Up Hood Lifter Assembly RH
- A 54 No. 2 Pop Up Hood Lifter Assembly LH
- A 55 No. 2 Pop Up Hood Lifter Assembly RH
- A 56 ECM

Position of Parts in Engine Compartment <RHD>



Position of Parts in Engine Compartment <RHD>

