


G ELECTRICAL WIRING ROUTING

Position of Parts in Instrument Panel

[LHD]



K 4 Keyless Buzzer On/Off SW

K 5 Kick Down SW

L 1 Luggage Compartment Door Opener SW

M 1 Multi-Display

M 2 Multi-Display

M 3 Multi-Display

O 3 Outer Mirror SW

O 4 Outer Mirror SW

O 5 Outer Mirror SW

P 2 Parking Brake SW

P 3 Passenger Side J/B ECU

P 4 Passenger Side J/B ECU

P 5 Passenger Side J/B ECU

P 6 Power Outlet

P 7 Power Tilt and Power Telescopic ECU

P 8 Power Tilt and Power Telescopic ECU