


E ELECTRICAL WIRING ROUTING

Position of Parts in Instrument Panel

[RHD]



K 4 Keyless Buzzer On/Off SW
K 5 Kick Down SW
K 6 Knee Airbag Squib LH
K 7 Knee Airbag Squib RH

L 1 Luggage Compartment Door Opener SW

M 1 Multi-Display
M 2 Multi-Display

O 3 Outer Mirror SW
O 4 Outer Mirror SW
O 5 Outer Mirror SW

P 2 Parking Brake SW
P 3 Passenger Side J/B ECU
P 4 Passenger Side J/B ECU
P 5 Passenger Side J/B ECU
P 6 Power Outlet
P 7 Power Tilt and Power Telescopic ECU
P 8 Power Tilt and Power Telescopic ECU
P52 PPS ECU
P53 Pressure SW