


Position of Parts in Body

[RHD]



M 4 Moon Roof Control ECU

N 5 Navigation ECU

N 6 Navigation ECU

N 7 Noise Filter (Rear Window Defogger)

O 6 Overhead J/B

P 9 Power Window Control SW Front LH

P 11 Power Window Control SW Rear LH

P 12 Power Window Control SW Rear RH

P 13 Power Window Master SW

P 14 Power Window Motor Front LH

P 15 Power Window Motor Front RH

P 16 Power Window Motor Rear LH

P 17 Power Window Motor Rear RH

P 18 Pretensioner Front LH

P 19 Pretensioner Front RH

P 20 Pretensioner Rear LH

P 21 Pretensioner Rear RH

R 8 Rain Sensor

R 9 Rear A/C Unit

R10 Rear Combination Light LH

R11 Rear Combination Light LH

R12 Rear Combination Light RH

R13 Rear Combination Light RH

R14 Rear Door LH ECU

R15 Rear Door LH ECU

R16 Rear Door RH ECU

R17 Rear Door RH ECU

R18 Rear Door Speaker LH

R19 Rear Door Speaker RH

R20 Rear Height Control Valve

R21 Rear Seat Memory SW LH

R22 Rear Seat Memory SW RH

R23 Rear Sunshade Control Relay

R24 Rear Window Defogger

R25 Rear Window Defogger

R26 Room Oscillator (Rear)

R30 Rear Door Outside Handle LH

R31 Rear Door Outside Handle RH