














SUSPENSION AND AXLE













SST (Special Service Tools)

PP3EZ-01









	09214-76011	Crankshaft Pulley Replacer	Front axle Rear axle
	09223-46011	Crankshaft Front Oil Seal Replacer	Rear differential
	09223-56010	Crankshaft Rear Oil Seal Replacer	Rear differential
	09229-55010	Oil Cooler Relief Valve Wrench	Rear differential
	09240-00020	Wire Gauge Set	Rear drive shaft
	(09242-00080)	Wire Gauge	
	09255-10012	Crankshaft Rear Bearing Remover & Replacer	Rear differential
	09308-00010	Oil Seal Puller	Rear differential
	09309-36010	Transmission Rear Bearing Replacer	Rear drive shaft
	09316-12010	Transfer Bearing Replacer	Rear differential
	09316-60011	Transmission & Transfer Bearing Replacer	Rear differential
	(09316-00011)	Replacer Pipe	





PREPARATION - SUSPENSION AND AXLE

	(09316-00041) Replacer "C"	
	09325-40010 Transmission Oil Plug	Rear differential
	09330-00021 Companion Flange Holding Tool	Rear differential
	09502-12010 Differential Bearing Replacer	Rear drive shaft Rear differential
	09502-24010 Bearing Replacer	Rear differential
	09520-24010 Differential Side Gear Shaft Puller	Rear differential
	09520-00031 Rear Axle Shaft Puller	Front axle
	(09520-00040) Shocker	
	(09521-00020) Rod with Grip	
	09521-24010 Drive Shaft Boot Clamping Tool	Rear drive shaft
	09570-24010 Differential Mounting Cushion Remover & Replacer	Rear differential
	09608-04031 Front Hub Inner Bearing Cone Replacer	Rear differential
	09608-32010 Steering Knuckle Oil Seal Replacer	Rear differential

	09610-20012	Pitman Arm Puller	Front suspension Rear suspension
	09613-26010	Steering Worm Bearing Cone Remover	Front suspension
	09628-00011	Ball Joint Puller	Rear suspension
	(09628-00030)	Power Unit	
	(09628-00040)	Jaw	
	(09628-00050)	Crow A	
	09628-10011	Ball Joint Puller	Front axle Rear axle
	09628-62011	Ball Joint Puller	Front suspension
	09710-30050	Suspension Arm Bushing Replacer	Rear differential
	09726-12023	Lower Suspension Arm Bushing Remover & Replacer	Rear drive shaft
	(09726-01031)	Spacer	
	09727-30021	Coil Spring Compressor	Front suspension Rear suspension
	09730-00010	Tube Remover	Front pneumatic cylinder Rear pneumatic cylinder Height control valve

PREPARATION - SUSPENSION AND AXLE

	09843-18040	Diagnosis Check Wire No.2	Diagnostic trouble code check
	09950-00020	Bearing Remover	Front Axle Rear differential
	09950-40011	Puller B Set	Rear differential
	(09951-04020)	Hanger 200	
	(09952-04010)	Slide Arm	
	(09953-04030)	Center Bolt 200	
	(09954-04010)	Arm 25	
	(09955-04061)	Claw No.6	
	(09957-04010)	Attachment	
	(09958-04011)	Holder	
	09950-60010	Replacer Set	
	(09951-00450)	Replacer 45	Rear differential
	(09951-00510)	Replacer 51	Rear differential

	(09951-00650) Replacer 65	Front axle
	09950-60020 Replacer Set No.2	Rear differential
	(09951-00710) Replacer 71	
	(09951-00780) Replacer 78	
	(09951-00810) Replacer 81	
	(09951-00890) Replacer 89	
	09950-70010 Handle Set	Rear differential
	(09951-07150) Handle 150	