

FOREWORD

This wiring diagram manual has been prepared to provide information on the electrical system of the LS 430.

Applicable models: UCF30 Series

For service specifications and repair procedures of the above models other than those listed in this manual, refer to the following manuals;

Manual Name	Pub. No.
• LEXUS LS 430 Repair Manual Volume 1 Volume 2	RM792E1 RM792E2
• LEXUS LS 430 New Car Features	NCF194E

All information in this manual is based on the latest product information at the time of publication. However, specifications and procedures are subject to change without notice.

TOYOTA MOTOR CORPORATION

NOTICE

When handling supplemental restraint system components (removal, installation or inspection, etc.), always follow the direction given in the repair manuals listed above to prevent accidents and supplemental restraint system malfunction.

English

Français

Español

Deutsch

LHD

RHD