


Position of Parts in Instrument Panel

[LHD]



D 1 DLC3
D 2 Driver Side J/B ECU
D 3 Driver Side J/B ECU
D 4 Driver Side J/B ECU
D 5 Driver Side J/B ECU
D 6 Duct Sensor (Driver's Side)
D 7 Duct Sensor (Front Passenger's Side)

E 11 ECT Pattern Select SW

F 12 Fuel Lid Opener SW
F 13 Fuel Lid Opener SW Illumination

G 1 Gateway ECU
G 2 Glove Box Light No.1
G 3 Glove Box Light No.2

H17 Hazard SW
H18 Headlight Beam Level Control ECU
H19 Heated Oxygen Sensor (Bank 1 Sensor 2)
H20 Heated Oxygen Sensor (Bank 2 Sensor 2)
H21 Height Control SW

I 17 Ignition SW
I 18 Instrument Panel Register

J 9 Junction Connector
J 10 Junction Connector
J 11 Junction Connector
J 12 Junction Connector
J 13 Junction Connector
J 14 Junction Connector
J 15 Junction Connector
J 16 Junction Connector
J 17 Junction Connector
J 18 Junction Connector
J 19 Junction Connector
J 20 Junction Connector
J 21 Junction Connector