


# AUTOMATIC AIR CONDITIONER (FRONT) [LHD]


FROM POWER SOURCE SYSTEM (SEE PAGE 180)





# AUTOMATIC AIR CONDITIONER (FRONT) [LHD]


FROM POWER SOURCE SYSTEM (SEE PAGE 180)



A14 (A), A15 (B), A16 (C)  
A/C CONTROL ASSEMBLY


\* 1 : W/O LEXUS NAVIGATION SYSTEM  
 \* 2 : EUROPE  
 \* 3 : W/ LEXUS NAVIGATION SYSTEM

\* 4 : W/ REAR POWER SEAT  
 \* 5 : W/O REAR POWER SEAT




A14 (A), A15 (B), A16 (C)  
 A/C CONTROL ASSEMBLY

# AUTOMATIC AIR CONDITIONER (FRONT) [LHD]




\* 1 : W/O LEXUS NAVIGATION SYSTEM  
 \* 2 : W/ REAR COOLER

FROM POWER SOURCE SYSTEM (SEE PAGE 180)




A14 (A), A15 (B), A16 (C)  
 A/C CONTROL ASSEMBLY

# AUTOMATIC AIR CONDITIONER (FRONT) [LHD]




A14 (A), A15 (B), A16 (C)  
A/C CONTROL ASSEMBLY



A14 (A), A15 (B), A16 (C)  
A/C CONTROL ASSEMBLY

# AUTOMATIC AIR CONDITIONER (FRONT) [LHD]



A14 (A), A15 (B), A16 (C)  
A/C CONTROL ASSEMBLY