

**SERVICE HINTS****I17 IGNITION SW**1-3 : Closed with ignition key at **ON** or **ACC** position1-2 : Closed with ignition key at **ON** or **ST** position5-6 : Closed with ignition key at **ON** or **ST** position5-4 : Closed with ignition key at **ST** position**○ : PARTS LOCATION**

Code	See Page	Code	See Page	Code	See Page
I17	117 (LHD)	J7	114 (LHD)	J14	B 117 (LHD)
J3	114 (LHD)	J13	A 117 (LHD)	J24	121 (LHD)

**○ : RELAY BLOCKS**

Code	See Page	Relay Blocks (Relay Block Location)
1	81	Engine Room No.1 R/B (Engine Compartment Left)
4	84 (LHD)	Fusible Link Block (Engine Compartment Right)

**○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR**

Code	See Page	Junction Block and Wire Harness (Connector Location)
1A	81	Engine Room Main Wire and Engine Room No.1 J/B (Engine Compartment Left)
1B		
4A	84 (LHD)	Engine Room Main Wire and Fusible Link Block (Engine Compartment Right)
4B		
4C		
4D		
4E		
4F		
DA	88 (LHD)	Engine Room Main Wire and Driver Side J/B (Left Kick Panel)
DC		
DE	87 (LHD)	Instrument Panel Wire and Driver Side J/B (Left Kick Panel)
DF		
DG		
LA	110	Floor No.2 Wire and Luggage Room J/B (Luggage Room Left)
LL		
PA	93 (LHD)	Engine Room Main Wire and Passenger Side J/B (Right Kick Panel)
PB		
PC		
PE	94 (LHD)	Instrument Panel Wire and Passenger Side J/B (Right Kick Panel)
PF		
PG		

**□ : CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS**

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IB2	142 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Cowl Side Panel LH)
IE1	142 (LHD)	Engine Room Main Wire and Floor No.2 Wire (Left Kick Panel)
IH3	144 (LHD)	Instrument Panel Wire and Engine Room Main Wire (Cowl Side Panel RH)

**▽ : GROUND POINTS**

Code	See Page	Ground Points Location
EC	140 (LHD)	Radiator Side Support LH
IG	142 (LHD)	Left Side of Instrument Panel
II	142 (LHD)	Right Side of Shift Lever
BM	146 (LHD)	Quarter Panel LH

## POWER SOURCE (LHD)

---



: SPLICE POINTS

Code	See Page	Wire Harness with Splice Points	Code	See Page	Wire Harness with Splice Points
E10	140 (LHD)	Engine Room Main Wire			

