



## Connector Joining Wire Harness and Wire Harness

**BF2**



**BG3**



Code	Joining Wire Harness and Wire Harness (Connector Location)
BF2	Floor No.2 Wire and Front Seat LH Wire (Under the Driver 's Seat)
BG3	Floor Wire and Front Seat RH Wire (Under the Front Passenger's Seat)