View A

DD

(from Engine Room Main Wire)

DC

(from Engine Room Main Wire)

D-ACC Relay

D-IG1 Relay

DA

(from Engine Room Main Wire)