










STARTING & CHARGING**PREPARATION**

023F6-01



SST

	09223-00010	Cover & Seal Replacer	GENERATOR ASSY
	09285-76010	Injection Pump Camshaft Bearing Cone Replacer	GENERATOR ASSY
	09820-00021	Alternator Rear Bearing Puller	GENERATOR ASSY
	09820-00031	Alternator Rotor Rear Bearing Replacer	GENERATOR ASSY
	09820-63010	Alternator Pulley Set Nut Wrench Set	GENERATOR ASSY
	09820-63011	Alternator Pulley Set Nut Wrench Set	GENERATOR ASSY
	09950-40011	Puller B Set	GENERATOR ASSY
	(09951-04020)	Hanger 200	GENERATOR ASSY
	(09952-04010)	Slide Arm	GENERATOR ASSY
	(09953-04020)	Center Bolt 150	GENERATOR ASSY
	(09954-04010)	Arm 25	GENERATOR ASSY
	(09955-04071)	Claw No.7	GENERATOR ASSY

PREPARATION - STARTING & CHARGING

	(09958-04011) Holder	GENERATOR ASSY
	09950-60010 Replacer Set	GENERATOR ASSY

Recommended Tools

	09082-00040 TOYOTA Electrical Tester	STARTER SYSTEM STARTER ASSY CHARGING SYSTEM GENERATOR ASSY
	(09083-00150) Test Lead Set	STARTER SYSTEM STARTER ASSY CHARGING SYSTEM GENERATOR ASSY

Equipment

Ammeter	
Battery	
Dial indicator	
Ohmmeter	
Press	
Pull scale	
Radiator cap tester	
Service wire harness	
Sandpaper (#400)	
Torque wrench	
V-block	
Vernier calipers	