











SUPPLEMENTAL RESTRAINT SYSTEM

PREPARATION

023EC-01

SST

	09082-00700	SRS Airbag Deployment Tool	FRONT PASSENGER AIRBAG ASSY HORN BUTTON ASSY INSTRUMENT PANEL AIR BAG ASSY LOWER NO.1 CURTAIN SHIELD AIR BAG ASSY LH FRONT SEAT AIRBAG ASSY LH INSTRUMENT PANEL AIR BAG ASSY LOWER NO.2
	09082-00750	Airbag Deployment Wire Sub-harness No.3	FRONT SEAT AIRBAG ASSY LH
	09082-00760	Airbag Deployment Wire Sub-harness No.4	CURTAIN SHIELD AIR BAG ASSY LH
	09082-00770	Airbag Deployment Wire Sub-harness No.5	INSTRUMENT PANEL AIR BAG ASSY LOWER NO.1 INSTRUMENT PANEL AIR BAG ASSY LOWER NO.2
	09082-00780	Airbag Deployment Wire Sub-harness No.6	FRONT PASSENGER AIRBAG ASSY HORN BUTTON ASSY
	09082-00802	Airbag Deployment Wire Sub-Harness No. 8	HORN BUTTON ASSY
	(09082-10801)	Wire A	HORN BUTTON ASSY
	(09082-30801)	Wire C	HORN BUTTON ASSY
	09950-50013	Puller C Set	FRONT PASSENGER AIRBAG ASSY SPIRAL CABLE SUB-ASSY
	(09951-05010)	Hanger 150	FRONT PASSENGER AIRBAG ASSY SPIRAL CABLE SUB-ASSY
	(09952-05010)	Slide Arm	FRONT PASSENGER AIRBAG ASSY SPIRAL CABLE SUB-ASSY

PREPARATION - SUPPLEMENTAL RESTRAINT SYSTEM

	(09953-05020) Center Bolt 150	FRONT PASSENGER AIRBAG ASSY SPIRAL CABLE SUB-ASSY
	(09954-05021) Claw No.2	FRONT PASSENGER AIRBAG ASSY SPIRAL CABLE SUB-ASSY

Recommended Tools

	09042-00010 Torx Socket T30	FRONT PASSENGER AIRBAG ASSY HORN BUTTON ASSY SPIRAL CABLE SUB-ASSY SEAT POSITION AIR BAG SENSOR
	09042-00020 Torx Socket T40	AIR BAG SENSOR ASSY CENTER

Equipment

Torque wrench	
Bolt Length: 35.0 mm (1.378 in.) Pitch: 1.0 mm (0.039 in.) Diameter: 6.0 mm (0.236 in.)	Airbag disposal
Tire Width: 185 mm (7.28 in.) Inner diameter: 360 mm (14.17 in.)	Airbag disposal
Tire with disc wheel Width: 185 mm (7.28 in.) Inner diameter: 360 mm (14.17 in.)	Airbag disposal
Plastic bag	Airbag disposal