


**CRUISE CONTROL****PREPARATION**

023DI-01

**SST**

	09870-60000 LAZER RADAR ADJUSTING REFLECTOR	LASER SENSOR
	(09870-60010) BASE STAND	LASER SENSOR
	(09870-60020) REFLECTOR A	LASER SENSOR

**Recommended Tools**

	09042-00010 Torx Socket T30	CRUISE CONTROL MAIN SWITCH
---	-----------------------------	----------------------------

**Equipment**

Torque wrench	
---------------	--