























Position of Parts in Body <LHD From Sep. 2015 Production>




- M 3 Fuel Sender Gage Assembly (Sub)
- N 1 Fuel Pump , Fuel Sender Gauge Assembly (Main)
- N 3 No.1 Height Control Valve Assembly
- N 4 Rear Height Control Sensor Sub-Assembly RH
- N 5 Rear Shock Absorber Assembly RH
- N 6 Rear Height Control Sensor Sub-Assembly LH
- N 7 Rear Shock Absorber Assembly LH
- N 10 Front Shock Absorber Assembly LH
- N 11 Front Shock Absorber Control Valve Assembly LH
- N 12 Fuel Pump Control ECU Assembly
- N 13 Front Shock Absorber Assembly RH
- N 14 Front Shock Absorber Control Valve Assembly LH
- N 15 Parking Brake with Bracket Actuator Assembly
- N 16 Front Shock Absorber Assembly RH
- N 17 Front Shock Absorber Control Valve Assembly LH
- N 18 DPF Temperature Sensor RH (Exhaust Gas Temperature Sensor)
- N 19 Differential Pressure Sensor RH
- O 5 Rear Fog Light Assembly RH
- O 6 Rear Fog Light Assembly LH
- O 11 No. 2 Ultrasonic Sensor RH
- O 12 No. 3 Ultrasonic Sensor RH
- O 13 No. 3 Ultrasonic Sensor LH
- O 14 No. 2 Ultrasonic Sensor LH
- e 1 Fuel Temperature Sensor
- e 2 Pressure Accumulator Sensor
- f 1 Back Door Remote Control Assembly
- f 2 Tail Gate Lock Assembly Lower RH
- f 3 Tail Gate Lock Assembly Lower LH
- f 4 Back-Up Light Assembly RH
- f 5 Back-Up Light Assembly LH
- g 5 Step Light Assembly LH
- g 6 Step Light Assembly RH


Position of Parts in Body <LHD From Sep. 2015 Production>



f 5
Gray



g 5
Gray



g 6
Gray

