




REMOVAL

1. **REMOVE INSTRUMENT PANEL SAFETY PAD**
(See page [BO-98](#))
2. **REMOVE AMPLIFIER**
 - (a) Disconnect the connector.
 - (b) Remove the screw and amplifier.