



## CIRCUIT



## SHIFT POSITION INDICATOR



| Terminal | Wiring connector side                   |
|----------|-----------------------------------------|
| 1        | Light Control Rheostat-terminal A       |
| 2        | TAIL Fuse                               |
| 3        | Park/Neutral Position Switch-terminal 6 |
| 4        | Park/Neutral Position Switch-terminal 1 |
| 5        | Park/Neutral Position Switch-terminal 5 |
| 6        | Ground                                  |
| 7        | Park/Neutral Position Switch-terminal 7 |
| 8        | O/D OFF Switch                          |
| 9        | GAUGE Fuse                              |
| 10       | Park/Neutral Position Switch-terminal 3 |
| 11       | Park/Neutral Position Switch-terminal 8 |
| 12       | ECM                                     |
| 13       | Pattern Select Switch                   |

N14141

V06501