





ADJUSTMENT

FUEL FILLER OPENING LID ADJUST

(a) Loosen the 2 screws.



(b) Adjust the fuel lid according to the following method.