

QUARTER BELT MOULDING REMOVAL


B03FP-01

1. REMOVE THESE PARTS (See page [BO-78](#))

- (a) No.2 rear seat
- (b) Back door scuff plate
- (c) Quarter trim
- (d) Rear door scuff plate
- (e) Rear seat side garnish
- (f) Quarter pillar garnish
- (g) Assist grip

2. LOOSEN ROOF HEADLINING

3. REMOVE VENT LOUVER



4. REMOVE QUARTER BELT MOULDING

Pry out the clip from the edge of the panel and remove the moulding.