

INSTALLATION

Installation is in the reverse order of removal (See page [BR-9](#)).

BEFOR INSTALLATION ADJUST LENGTH OF BRAKE BOOSTER PUSH ROD AFTER INSTALLATION, FILL BRAKE RESERVOIR WITH BRAKE FLUID BRAKE SYSTEM (See page [BR-4](#)), CHECK FOR CEAKS, CHECK AND ADJUST BRAKE PEDAL (See page [BR-6](#))

HINT:

- Before installation, adjust length of brake booster push rod (See page [BR-18](#)).
- After installation, fill brake reservoir with brake fluid, bleed brake system (See page [BR-4](#)).
- Check for leaks, check and adjust brake pedal (See page [BR-6](#)).