


















SUSPENSION AND AXLE








SST (Special Service Tools)

PP38W-01




	09214-76011 Crankshaft Pulley Replacer	Front differential Rear differential
	09223-15020 Oil Seal & Bearing Replacer	Front differential Rear axle
	09226-10010 Crankshaft Front & Rear Bearing Replacer	Rear suspension
	09308-00010 Oil Seal Puller	Front axle Front differential Rear axle Rear differential
	09308-10010 Oil Seal Puller	Front differential Rear differential
	09315-00022 Clutch Release Bearing Remover & Replacer	Rear differential
	09316-20011 Transfer Bearing Replacer	Rear suspension
	09316-60011 Transmission & Transfer Bearing Replacer	Front differential Rear differential
	(09316-00011) Replacer Pipe	
	(09316-00021) Replacer "A"	
	(09316-00051) Replacer "D"	
	09330-00021 Companion Flange Holding Tool	Front differential Rear differential

PREPARATION - SUSPENSION AND AXLE

	09504-00011 Differential Side Bearing Adjusting Nut Wrench	Front differential Rear differential
	09504-22011 Differential Side Bearing Replacer	Rear differential
	09506-35010 Differential Drive Pinion Rear Bearing Replacer	Rear differential Rear suspension
	09509-25011 Rear Axle Bearing Lock Nut Wrench	Rear axle
	09517-36010 Rear Axle Shaft Oil Seal Replacer-	Rear axle
	09550-60010 Differential Side Bearing Replacer	Rear differential
	09556-22010 Drive Pinion Front Bearing Remover	Front differential Rear differential
	09605-60010 Steering Knuckle Bearing Cup Replacer-	Front axle
	09606-60020 Steering Knuckle Bearing Remover	Front axle
	09607-60020 Front Wheel Adjusting Nut Wrench	Front axle
	09611-22012 Tie Rod End Puller	Front axle
	09612-65014 Steering Worm Bearing Puller	Front axle
	(09612-01010) Claw "A"	

	(09612-01050) Hanger Pin with Nut	
	09618-60010 Front Axle & Drive Shaft Bearing Replacer	Front axle
	09710-22021 Front Suspension Bushing Tool Set	Rear suspension
	(09710-01071) Lower Arm Bushing Remover	
	09710-22042 Rear Suspension Bushing Tool Set	Front suspension
	(09710-02051) Base	
	(09710-02061) Replacer	
	(09710-02071) Bushing Remover & Replacer	
	09710-30050 Suspension Arm Bushing Replacer	Front suspension
	09726-40010 Lower Control Shaft Bearing Replacer	Front differential Rear differential
	09727-30021 Coil Spring Compressor	Front suspension
	09950-00020 Bearing Remover	Front differential Rear differential
	09950-30011 Puller A Set	Front differential Rear differential

PREPARATION - SUSPENSION AND AXLE

	09950-40011 Puller B Set	Front differential Rear differential
	09950-60010 Replacer Set	Front differential Rear differential Rear suspension
	09950-60020 Replacer Set No.2	Front axle Rear axle Rear differential
	09950-70010 Handle Set	Front axle Front suspension Rear axle Rear differential Rear suspension