




QUARTER PANEL EXTENSION (ASSY)

REMOVAL (With the quarter panel removed.)



INSTALLATION

