




ENGINE COOLANT TEMPERATURE (ECT) CUT RELAY REMOVAL

AC2V7-01

1. REMOVE INSTRUMENT PANEL (See page [BO-98](#))
2. REMOVE ENGINE COOLANT TEMP. CUT RELAY FROM COOLING UNIT