

FRONT DOOR BELT MOULDING REMOVAL

B03FL-01

1. REMOVE THESE PARTS (See page [BO-12](#)):

- (a) Door inside handle bezel
- (b) Armrest
- (c) Armrest panel base upper
- (d) Courtesy light
- (e) Lower frame bracket garnish
- (f) Door trim

2. REMOVE FRONT DOOR BELT MOULDING

Pry out the clip from the edge of the panel and remove the moulding.

