


QUARTER BELT MOULDING REMOVAL

B03FP-01

1. **REMOVE THESE PARTS (See page [BO-78](#))**
 - (a) No.2 rear seat
 - (b) Back door scuff plate
 - (c) Quarter trim
 - (d) Rear door scuff plate
 - (e) Rear seat side garnish
 - (f) Quarter pillar garnish
 - (g) Assist grip
2. **LOOSEN ROOF HEADLINING**
3. **REMOVE VENT LOUVER**



4. **REMOVE QUARTER BELT MOULDING**

Pry out the clip from the edge of the panel and remove the moulding.