




REPLACEMENT

REPLACE REAR DOOR GLASS

- (a) Remove glass channel with screwdriver or similar object.
- (b) Apply soapy water to inside of weatherstrip.
- (c) Install channel by tapping it with plastic hammer.