




ROCKER PANEL MOULDING REMOVAL

B03FV-01

REMOVE ROCKER PANEL MOULDING

- (a) Remove the 8 screws.
- (b) Remove the rocker panel moulding.

HINT:

Remove the rocker panel moulding in the same way as the front door outside moulding.