




REAR QUARTER PANEL PROTECTOR REMOVAL

B03FT-01

REMOVE REAR QUARTER PANEL PROTECTOR

- (a) Remove the 2 screws and side marker light.
- (b) Remove the rear quarter panel protector.

HINT:

Remove the rear quarter panel protector in the same way as the front door outside moulding.