





REPLACEMENT

REPLACE BUSHINGS

Using SST and a press, replace the bushing from the leading arm.

SST Front side: 09710-30050

SST Rear side: 09710-22042 (09710-02061)



HINT:

When assembling a new bushing, as shown in the illustration.