

INSTALLATION

1. INSTALL IAC VALVE

- (a) Place a new O-ring on the throttle body.
- (b) Install the IAC valve with the 2 screws.

2. INSTALL THROTTLE BODY