

TORQUE SPECIFICATION

Part tightened	N·m	kgf·cm	ft·lbf
Fuel line for union bolt for flare nut	29	300	22
	30	310	22
Second seat x Body	39	400	29
Fuel pump bracket assembly x Fuel tank	3.9	40	35 in.·lbf
Fuel inlet hose x Fuel filter	29	300	22
Fuel inlet pipe x Fuel filter	29	300	22
Fuel filter x Intake manifold	21	210	15
Fuel pressure regulator x Delivery pipe	25	250	18
Delivery pipe x Intake manifold	21	210	15
Fuel inlet pipe x Delivery pipe (Union bolt)	29	300	22
Fuel inlet pipe x Delivery pipe (Bolt)	20	200	14
Fuel inlet pipe x Fuel filter	29	300	22
Fuel return pipe x Intake manifold	20	200	14
Air intake chamber x Intake manifold	21	210	15
Intake manifold stay x Air intake chamber, Cylinder block	36	360	26
PS reservoir tank x Air intake chamber	18	185	13
Heater inlet pipe x Air intake chamber	20	200	14
Drain plug x Fuel tank	6.5	65	57 in.·lbf
Fuel tank breather tube x Fuel tank	1.5	15	13 in.·lbf
Fuel tank filler pipe x Fuel tank	3.5	35	31 in.·lbf
Fuel tank band x Body	39	400	29
MAF meter x Bracket, Air cleaner cap	6.9	70	61 in.·lbf
Throttle body x Air intake chamber	21	210	15
Fuel pump resistor x Body	18	185	13
ECT sensor x Cylinder head	24.5	250	17.5
EGR gas temperature sensor x Air intake chamber	20	200	14
Knock sensor x Cylinder block	44	450	33
Heated oxygen sensor (Bank 1 Sensor 1) x Front exhaust pipe	20	200	14
Heated oxygen sensor (Bank 1 Sensor 2) x Center pipe	20	200	14