

DTC	P1566/54	Input Signal Circuit
------------	-----------------	-----------------------------

CIRCUIT DESCRIPTION

See page [DI-654](#).

DTC No.	Detection Item	Trouble Area
P1566/ 54	• Input signal abnormal.	• ECM

INSPECTION PROCEDURE

Check and replace ECM (See page [IN-34](#)).