





CYLINDER HEAD COMPONENTS


EMOMH-01




B04614








A04461



A05561



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

A05527