

INSTALLATION

Installation is in the reverse order of removal (See page [SA-97](#)).

AFTER INSTALLATION, FILL REAR DIFFERENTIAL WITH HYPOID GEAR OIL (See page [SA-92](#)), FILL BRAKE RESERVOIR WITH BRAKE FLUID, BLEED BRAKE SYSTEM (See page [BR-4](#)), CHECK FOR LEAKS AND CHECK ABS SPEED SENSOR SIGNAL (See page [DI-309](#))