




SERVICE HINTS

C11 CLOCK [CENTER ECU]

2-GROUND : Approx. **12** volts with ignition SW at **ACC** or **ON** position
 12-GROUND : Always approx. **12** volts
 22-GROUND : Always continuity

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C11	38	J1	39		


□ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
2B	24	Dash Wire and Cowl Side J/B LH (Left Kick Panel)
2D		


▽ : GROUND POINTS

Code	See Page	Ground Points Location
IF	46	Set Bolt of Cowl Side J/B LH

C11



J1



(Hint : See Page 7)