




BODY LOWER BACK PANEL (CUT)


REMOVAL



1. Cut and join the parts at the locations as shown above.

mm	in.
220	8.66
90	3.54




INSTALLATION



1. Temporarily install the new parts and check the fit of the tail gate.




BODY LOWER BACK PANEL (CUT)


REMOVAL (With the quarter panel rear extension removed.)



1. Cut and join the parts at the locations as shown above.

mm	in.
220	8.66
90	3.54



INSTALLATION

Back Door Opening
Lower Reinforcement

