




STARTER COMPONENTS

ST08Y-01




B04884





Magnetic Switch Assembly



◆ Non-reusable part

B04547